

Fitting Guide For Roller Blinds

Tools Required

- a pencil
- a screwdriver
- a drill (8mm drill bit)
- a small stepladder (optional)

In Your Parcel

Your roller blind.

Brackets as follows:



(You'll receive either one of each or two cross brackets, depending on your blind size).

Child safety box for storing loose cables.

STEP 1 - FIX UP THE BRACKETS

Clip the end pins into the brackets and slot them onto the end of the roller blind in order to measure your drilling positions. Make sure that the bracket containing a cross shape is on the side of your controls (for larger blinds, both brackets contain a cross shape).

The same bracket is used for face fixing and top fixing, just turn it to face either the wall or your lintel. Place the blind in your window area and use a pencil to mark where you need to drill.

Drill the holes and screw the brackets into place, using raw plugs if necessary.

STEP 2 - FIT YOUR BLIND

The non-control end of your blind is spring loaded, so slot this into place first and then clip the control end into place, ensuring that the end of your headrail aligns and locks into position correctly in the bracket.