

Fitting Guide For Venetian Blinds

Tools Required

- a pencil
- a screwdriver
- a drill (8mm drill bit)
- a small stepladder (optional)

In Your Parcel

Your venetian blind with control wand attached.

Brackets - either:

1. 16mm/25mm Face Fix
2. 16mm/25mm Top Fix
3. 35mm/50mm Top Fix or Face Fix



1.



2.

3.

Child safety cleat.

STEP 1 - FIX UP THE BRACKETS

Place the headrail into place and mark your bracket positions, ensuring that you have clearance from any window handles etc. Brackets ideally need to be positioned 5cm away from the side but also at least 5cm away from your blind controls.



Before fitting, move the 'swing arm' on the bracket forward as far as it will go. Screw brackets into place, using raw plugs where necessary.

STEP 2 - ATTACH THE HEADRAIL

16mm / 25mm

With the controls facing you, place the headrail below the bracket and hook the front over the two lips on the front of the bracket. Push the swing arm back to lock the headrail into place.

35mm / 50mm

Place the headrail in position on the underside of the 'swing arm' and push the arm back to hold the headrail up and lock it into place.

STEP 3 - OPERATING YOUR BLINDS

Use the tilt wand to tilt the slats and the cords to raise and lower your blind. Pulling the cords to your left will unlock the raise mechanism and pulling the cords to your right will lock it into place.

Be sure to attach the child safety cleat to the wall for wrapping excess cords around. Blinds that use cleats must be fitted at a minimum height of 1.5m by law. If you require a blind at a lower height then please view our alternative safety options.